Single Button Operation
1. Press Button for On or Off
2. To Control Brightness:
   From Off - Press and hold, release at desired brightness.
      Light will "blink" at full brightness.
   From On - Press and hold, release at desired brightness.
      Light will "blink" at lowest light level.
3. For Safety Beacons - Press and hold past "blink"
   You can choose Slow Beacon, Medium Beacon,
   Fast Flash, or S.O.S.
4. Signal/Morse Code (Squeeze only light) Press rapidly
   until light will not stay on.
   To exit Signal/Morse Code, press until light turns off

To Replace Batteries
1. Carefully remove the cap on the
   logo side by prying under the
   tab with a pointed tool, such
   as a ball point pen.
2. Replace with two **CR-2016**
   lithium batteries. Install with
   + side up and make sure
   the top battery is under the
   metal strip.
3. Replace the cap by aligning the
   tab and snapping shut.

Tab

Tab

1849 University Avenue
Berkeley CA 94703 USA

TEL: (510) 845-7178
FAX: (510) 845-7145

sales@forrestsmusic.com
www.forrestsmusic.com