

**Mounting the Adapter:**

Soft solder onto the bocal, with the center of the adapter 5/8" above the center of the bocal vent, and rotated towards the front far enough to clear the whisper pad (about 55°). **Make sure the whisper key and pad will clear the adapter and microphone.** Drill the hole #36 (.106")

**Mounting the pickup:**

Make sure the 'O' ring is in the groove in the adapter, then apply lubricant (water or cork grease) sparingly. Gently push and twist the pickup into place.

Forrests cannot predict and is not responsible for, possible changes in your bocal due to the installation of this product.

**Mounting the Adapter:**

Soft solder onto the bocal, with the center of the adapter 5/8" above the center of the bocal vent, and rotated towards the front far enough to clear the whisper pad (about 55°). **Make sure the whisper key and pad will clear the adapter and microphone.** Drill the hole #36 (.106")

**Mounting the pickup:**

Make sure the 'O' ring is in the groove in the adapter, then apply lubricant (water or cork grease) sparingly. Gently push and twist the pickup into place.

Forrests cannot predict and is not responsible for, possible changes in your bocal due to the installation of this product.

**Mounting the Adapter:**

Soft solder onto the bocal, with the center of the adapter 5/8" above the center of the bocal vent, and rotated towards the front far enough to clear the whisper pad (about 55°). **Make sure the whisper key and pad will clear the adapter and microphone.** Drill the hole #36 (.106")

**Mounting the pickup:**

Make sure the 'O' ring is in the groove in the adapter, then apply lubricant (water or cork grease) sparingly. Gently push and twist the pickup into place.

Forrests cannot predict and is not responsible for, possible changes in your bocal due to the installation of this product.

**Mounting the Adapter:**

Soft solder onto the bocal, with the center of the adapter 5/8" above the center of the bocal vent, and rotated towards the front far enough to clear the whisper pad (about 55°). **Make sure the whisper key and pad will clear the adapter and microphone.** Drill the hole #36 (.106")

**Mounting the pickup:**

Make sure the 'O' ring is in the groove in the adapter, then apply lubricant (water or cork grease) sparingly. Gently push and twist the pickup into place.

Forrests cannot predict and is not responsible for, possible changes in your bocal due to the installation of this product.