

**Mounting the Adapter:**

Soft solder onto the bocal,  
with the center of the  
adapter 1 7/8" [48mm] above  
the large end of the bocal  
Drill the hole 1/16"  
[1.58mm].

Forrests cannot predict, and  
is not responsible for, possi-  
ble changes in your bocal  
due to the installation of  
this product.

**Mounting the Adapter:**

Soft solder onto the bocal,  
with the center of the  
adapter 1 7/8" [48mm] above  
the large end of the bocal  
Drill the hole 1/16"  
[1.58mm].

Forrests cannot predict, and  
is not responsible for, possi-  
ble changes in your bocal  
due to the installation of  
this product.

**Mounting the Adapter:**

Soft solder onto the bocal,  
with the center of the  
adapter 1 7/8" [48mm] above  
the large end of the bocal  
Drill the hole 1/16"  
[1.58mm].

Forrests cannot predict, and  
is not responsible for, possi-  
ble changes in your bocal  
due to the installation of  
this product.

**Mounting the Adapter:**

Soft solder onto the bocal,  
with the center of the  
adapter 1 7/8" [48mm] above  
the large end of the bocal  
Drill the hole 1/16"  
[1.58mm].

Forrests cannot predict, and  
is not responsible for, possi-  
ble changes in your bocal  
due to the installation of  
this product.

**Mounting the Adapter:**

Soft solder onto the bocal,  
with the center of the  
adapter 1 7/8" [48mm] above  
the large end of the bocal  
Drill the hole 1/16"  
[1.58mm].

Forrests cannot predict, and  
is not responsible for, possi-  
ble changes in your bocal  
due to the installation of  
this product.

**Mounting the Adapter:**

Soft solder onto the bocal,  
with the center of the  
adapter 1 7/8" [48mm] above  
the large end of the bocal  
Drill the hole 1/16"  
[1.58mm].

Forrests cannot predict, and  
is not responsible for, possi-  
ble changes in your bocal  
due to the installation of  
this product.

